


NOTE: Cutting the wiring harness, antenna lead, USB, or AUX cable will void your warranty.

## Wiring Connections Motor 2A



**NOTE:** Cutting the wiring harness, antenna lead, USB, or AUX cable will void your warranty.

## Motor 1A Connect . **Main Wire Harness** to back of radio 15 AMP FUSE ·····▶ **ANTENNA AUX INPUT 1** Connect Power Wire Harness. and Speaker Wire Harness CONSTANT +12V **NOTE: Yellow** and Red wires (Yellow Wire) must be IGNITION/ACC (connect to +12V) connected to (Red Wire) +12V for radio **GROUND** to operate. (Black Wire) **POWER ANTENNA** NOTE: This radio is designed for (Blue Wire) use in vehicles REMOTE/AMP TURN-ON LEAD with a 12 volt negative ground (Blue/White Wire) system. **FRONT REAR** White/Black Grey/Black Purple/Black Stripe Purple Green/Black Green White Grey Stripe Stripe Stripe (+)(+)**4 OHM Right Speaker** Left Speaker Right Speaker Left Speaker (Front) (Front) (Rear) (Rear)

Wiring Connections

**NOTE:** Cutting the wiring harness, antenna lead, or AUX cable will void your warranty.